
How to assemble M4 Hotend







Install to the side of heat block



PTFE tube (2x4) Length = 42mm



Plug-in



1pc Insulation block 6pcs PM2.5x15 6pcs Shim (4.2x2.5x1)



Connect the Insulation and the heatsink




Connect the Insulation and the heatsink



Install nozzle


Winding high temperature adhesive tape
On the heating block

How to assemble M4 printhead










Install extruder FAN

Install cooler FAN

Install cartridge heater and tmeperature sensor

Winding high temperature adhesive tape On the heating block









Install the hotend into housing

Install fittings Install mounting screws

Install FAN duck